

The Recirculating Lab Faucet comes with the Recirculating Module and Tube temporarily assembled.

STEP 1. Remove the Recirculating Module and Recirculating Tube from the through deck nipple.

STEP 2. Mount the faucet in the desired location through a 1" diameter hole. Tighten to deck with the Ring Nut supplied.

STEP 3. Insert the Recirculating Tube into and through the Through Deck Nipple until the 3/8" male NPT thread mates with the 3/8" female NPT thread in the inlet connection of the Through Deck Nipple. Tighten by hand plus 1/4 wrench turn.


STEP 4. Connect the supply line to the 3/8" female NPT inlet connection.

STEP 5. Connect the recirculating return line to the 3/8" female NPT outlet connection.

STEP 6. Pressure test all connections.

Note: A high density PTFE tape is the recommended tread sealant.

SECTION C-C

| | | | |
|--|--|--|---|
| Designer | | | TITLE: Recirculating Lab Faucet Installation Instructions |
| Review | | | |
| Engineer | | | |
|  MARQUEST SCIENTIFIC <small>Fluid Handling Products</small> | | | DWG. NO. LG-DDR-INSTALL |
| <small>UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES</small> | | | SCALE: N/A Format: SD SHEET 1 OF 1 |